



Refer "Delta power kit parts breakdown" for more information

Note:  
Refer Delta power leg wiring schematic for more information

Remove all burrs and sharp edges

Torque Arm Table	
Part Number	Description
T-M000	Jost Modul B
T-MR000	Jost Modul B Reverse
T-A000	Jost A400/C200
T-AR000	Jost A400 Reverse
T-H000	Holland Mark V
T-HA000	Holland Atlas 55

Leg Drive Table	
Leg Drive Versions	Part No.
Extra Torque Drive	LE
Standard Drive	LD
Hi-speed Drive	LH
Ultra Hi-speed Drive	LU

PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	Refer leg drive table	Delta Drive (Harness not shown)
2	1	D-0205	Front Cap
3	1	D-0210	Cap Silicone Seal
4	1	D-0350	Rear Collar
5	1	P-1000	Power Kit (Harness not shown)
6	1	Refer torque arm table	Torque Arm
7	1	PN0064A	Drive Pin
8	1	E-M-1000	Remote bezel housing kit
9	1	RCHAP14	Horizontal remote

LINEAR DIMENSION TOL. (ISO-2768-f)						ANGULAR DIMENSION TOL. (ISO-2768-f)				
Nominal Length Range						Nominal Length Range				
FROM	0.5	>6	>30	>120	>400	0	>10	>50	>120	>400
TO	6	30	120	400	1000	10	50	120	400	
TOL.	±0.05	±0.1	±0.15	±0.2	±0.3	±1°	±0°30'	±0°20'	±0°10'	±0°5'

Designed by Ivan | Checked by | Approved by - date | Material | Date 24/04/2017 | Sheet 1 / 1  
**Razor International Pty Ltd**  
 Delta Leg Drive Kit  
 Drawing Number | Edition