



Refer to drawing "BKRA14" for more information

Torque Arm Table	
Part Number	Description
1026J	Jost Modul
1026JR	Jost Modul Reverse
1026A	Jost A400/C200
1026W	Jost A401
1026D	Jost D200
1026M	Maxus
1026K37	Fuwa KHitch37
1026K25	Fuwa KHitch25
1026K22	Fuwa KHitch22
1026H	Holland Mark V

PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	1026X	Torque arm(Refer seperate table)
2	1	LD14	Razor Leg Drive(Harness not shown)
3	1	PN0029A	Rubber boot
4	1	PN0047A	Boot clip
5	1	PN0053A	Housing boot clip
6	1	PN0064A	Drive pin
7	1	PN0023B	Front Cap
8	1	PN0023S	Cap Seal(BS116)
9	1	PN0055C	Collar
10	1	BKRA14	Battery kit(Harness not shown)
11	1	RCAPBE	AP Remote Bezel
12	1	RCHAP	Horizontal Remote

Note:
Refer to Razor power leg wiring schematic for more information

RAZOR ©

Designed by Ivan	Checked by	Approved by - date	Material	Date 22/01/2015	Sheet 1 / 1
Razor International Pty Ltd				Razor Leg kit assembly	
Drawing Number				Edition	